



Woodwind Instrument Servicing August 2010

Check Over

Re-seat pads and adjust regulation
Replace adjustment corks as required
Replace up to four pads (additional pads charged at £2.50–£4.00 per pad)

Service

Dismantle and clean body of instrument
Clean and lubricate keywork
Replace up to six pads (additional pads charged at £2.50–£4.50 per pad)
Replace regulation corks as required
Check and adjust pad seating and regulation

Re-Pad

Dismantle and clean body and keywork of instrument
Remove dents, check alignment of flute and saxophone body
Replace all pads and corks, check and adjust springs as necessary
Replacement springs are charged at £2.50 per spring if needed
Prices include skin pads (leather and Gortex pads are available at additional cost)

Prices

	Check Over	Service	Re-Pad
Flute/Piccolo	80.00	145.00	220.00
Clarinet (Bb / A / Eb)	80.00	125.00	215.00
Alto Clarinet	90.00	180.00	335.00
Bass Clarinet	115.00	215.00	380.00
Soprano Saxophone	110.00	210.00	350.00
Alto/Tenor Saxophone	110.00	235.00	370.00
Baritone Saxophone	160.00	335.00	460.00
Oboe (student)	110.00	200.00	335.00
Oboe (professional)	125.00	215.00	380.00
Cor Anglais	135.00	275.00	385.00
Bassoon (student)	135.00	230.00	420.00
Bassoon (professional)	165.00	295.00	450.00
On-the-spot Charges			
Tenon re-cork	22.00		
Saxophone crook re-cork	27.00		
Single flute/clarinet pad replacement	22.00		
Flute headjoint cork replacement	22.00		
Flute tenon tightening (per tenon)	27.00		

Minor work is charged at our standard hourly rate (there is no minimum charge).

*Prices are a guide only and may vary according to the age and condition of the instrument.
Cost of routine sundry items (felts, corks, pads etc.) and VAT at 17.5% are included in the quoted prices.*

The Old House, 64 London End, Beaconsfield, Bucks. HP9 2JD
Tel. Rosehill Sales: (01494) 671717 Fax: (01494) 676428 Email: info@rosehillinstruments.co.uk Website: www.rosehillinstruments.co.uk
Tel. Accounts Department: (01494) 685132